



Floor bathtub mixer instruction


Please inspection all spare parts list when you open box, if any problem, please contract with seller. Spare parts list as follow.




NO	Product Description	QTY
1	Faucet Body	1
2	Panel	1
3	I-BOX	1
4	Expansion screw	4
5	Handshower	1
6	PVC Hose	1
7	instruction	1
8	Screw Tool	1




NOTICE:




1.N-box in-wall depth:D<46mm
N-box more than 2mm of tiles.




2. Adjust level by gradiometer.
Fix by M6 expansion Screw.




3. Jointing hot and cold water joint. Prevent no leakage.




4.Clean.




5.Take spare parts, cover, test parts and gradiometer.




6.put on panel carefully to avoid scratch to the surface of faucet body




7.Fix flange with locking screw to faucet body firmly.



8.insert inner pipe vertically intooutlet of I-box



9.connect flange and I-box with locking screw, tighten with allen key.Close panel to the floor.



10.Fix shower hose and hand shower.

